

Fixing Instructions

GA Panels with GA Gravity Frames Type RC3

These instructions tell you about installing GA Panels with GA Gravity Frames Type RC3.

Please read these instructions before using this product. If there is anything you do not understand or if you want to know more about this item, please contact GA.

GA Panels with GA Gravity Frames must be installed by suitably qualified contractors with the required knowledge and expertise. Current standard construction methods must be used.

The installation contractor has the responsibility and duty to ensure proper safety so that during and after completion of the installation the panels remain safely positioned in the horizontal void.

Before beginning installation also refer to [GA Sitework Data Sheet](#) for additional guidance on Off-loading, Site Storage and Installation.

Step 1: Carefully unpack the materials.

Step 2: Inspect the GA Gravity Frame panels to ensure these are undamaged.

Step 3: Present the GA Gravity Frames to the horizontal void and carefully lower into position.

Step 4: If required, secure with suitable screws/ fixings (supplied by others) through the frame flange.

NB GA Panels supplied by Gooding Aluminium are not intended to have electrical wiring installed. Where this is a requirement the specifier and installer should ensure that all Regulations have been complied with and in particular that consideration has been given to the CENELEC HD 384 series of documents. (CENELEC HD 384 Series: Electrical Safety in Buildings (20 Parts)).

Issue 1:5/08

